



Automatic Insect Control System

OPERATING INSTRUCTIONS

(Please keep these instructions for future reference)

Using for the First Time

Choose a central location where air currents are likely to circulate and preferably close to the area where insect pests are most prevalent. You may need to test more than one location. Avoid areas with major through drafts.

Shelf Placement or Wall Hanging

Select a position at least 2 meters above the floor and not closer than 300mm from the ceiling. For wall hanging use the screws and plugs provided. Avoid installation over furniture and polished surfaces

Installing Batteries (not supplied)

Open the front cover by pushing down the ball on the top of the dispenser. Insert 4 X AA size batteries into the battery compartment. The flat negative (-) battery end to sit against the spring.

Switching On

When you have opened the front cover you will see 2 grey coloured buttons:

1 = ON/OFF. (on the right)

To turn the dispenser ON or OFF.

2 = SPRAY. (on the left)

When you push this button the dispenser will release one spray burst. NB. Ensure that the spray nozzle is facing away from you

Selecting Timing Option

The 3 black switches are 1- TIME SET. 2-OPERATION MODE SET. 3- LIGHT SENSOR

1 = TIME SET.

You can select three spray interval times, namely, 7.5 minutes, 15 minutes or 22.5 minutes. We recommend you start with 7.5 minute intervals and then adjust up until you reach the ideal time interval suitable for your particular environment.

2 = OPERATION MODE SET.

- a) MANUAL means the dispenser will only spray when you push the SPRAY button.
- b) AUTO & MANUAL means the dispenser will spray according to the timing setting you have chosen
- c) AUTO means the dispenser will spray according to the timing setting you have chosen but the MANUAL function will not operate.

3 = LIGHT SENSOR

The light sensor will allow you to choose between day, night or 24 hour operation.

DAY means the dispenser will operate when there is light.

24H means it will operate day and night.

NIGHT means it will operate only when it is dark.

LED Indicator

The GREEN LED will flash every 4 seconds to indicate that the dispenser is working normally. When the RED LED flashes, it means that the dispenser has fired 3000 times and your aerosol is empty or nearly empty and acts as a reminder to insert a refill aerosol. Please note that the RED LED will also flash every time the dispenser fires a burst.

Seasonal Operation

At the end of the summer season insects may not be as prolific. However, insects such as ants, fleas and cockroaches can be year round pests. It may be wise therefore to continue using the dispenser throughout the year.

One Year Warranty

Your RoboSol “Naturally Better” Automatic Aerosol Dispenser must be maintained according to these instructions.

The RoboSol dispenser is covered for 1 year from date of purchase. Warranty covers free repair or replacement of the dispenser due to any defects in materials or workmanship. Not covered under the warranty are deliberate misuse, breakage, normal wear and tear, repairs carried out by unauthorised persons or involving use of non-genuine RoboSol parts and refill cans.

This warranty in no way affects your rights under statutory law. Our liability shall not exceed the cost of the replacement dispenser and in no case shall be held liable for any consequential loss or damage or negligence resulting from the use of the dispenser or aerosol cans. Our liability for failing to perform the warranty obligations is similarly limited. The warranty does not include dispenser performance or battery life.

If faults develop please return immediately to your supplier or directly to us.

PLEASE REGISTER YOUR WARRANTY DETAILS ON THE ROBOSOL WEBSITE : www.robosol.co.za

Please contact us with any questions you may have concerning the use of RoboSol or should you experience difficulty in obtaining additional Dispensers and/or replacement Aerosols from your local supplier or for trouble shooting assistance or for more information please visit our website **www.robosol.co.za** or email: info@robosol.co.za or contact:

Mantelle Marketing Pty Ltd T/A RoboSol®

12 Mountbatten Ave, Pinelands, Cape Town,
South Africa. 7405

TEL : 27 21 531 071. FAX : 27 86 662 3662

E-mail: info@robosol.co.za. Website: www.robosol.co.za